

SOLINTEG MONITORING INTRODUCTION

Based on Monitoring version V3.2.0

www.solinteg.com


2023.8.1

INTEGRATE SOLAR INTELLIGENTLY



SOLAR INTELLIGENT


CONTENT



Monitoring Introduction



Solinteg-Cloud Operation



Solinteg APP Operation



SolintegSet Operation



01 Monitoring Introduction

SOELINTEG

Solinteg Monitoring Solutions

Solinteg-Cloud



Solinteg Cloud is Solinteg's self-developed official monitoring platform for end-users and distributors to monitor and manage their devices and plants. It features rich functions such as 24-hour load monitoring and devices and plants management, remote configuration and upgrading, organization management, alarms information, etc.

WWW.SOLINTEG-CLOUD.COM

Solinteg-App



Solinteg App is the portable version of the Solinteg cloud, allowing people to install it on their phones for monitoring and management of their devices and plants anytime, anywhere.





SolintegSet-App



SolintegSet App is designed for quick configuration of Solinteg **hybrid** inverters, offering features such as safety code, battery brand and type, work mode and off-grid application settings, etc.



Solinteg Monitoring Interfaces At A Glance



Plant Name	Device Name	SN	Alarm type	Start time	Alarm name	Alarm Status	Operate
Hybrid PV System	test device	8112200171030795	Protection	08:48:32 29/01/2023	Mains Lost	Restored	🔧
Hybrid PV System	test device	8112200171030795	Protection	08:46:32 29/01/2023	BMS Comm Fault	Restored	🔧
Hybrid PV System	test device	8112200171030795	Protection	17:02:26 17/01/2023	Mains Lost	Restored	🔧

Solinteg Monitoring Features

24 Hours
Load monitoring

Dashboard
Big screen

Download
Center

WiFi
Configuration

Remote
Upgrade

CT & Meter
Detection

Parameter
Report
Checking & Exporting

Warning
Reminder and solution

Vivid Energy Flow

Organization
Management

Parameter
Configuration

Smart Load
Management

Plant & Device
Level monitoring and
management



Solinteg Cloud Operation

SOLINTEG



Solinteg Cloud Operation Account Creation

SOLINTEG

Monitoring Platform Target Users

Organization Users



Organization users mean company users such as distributor or installer who doesn't use the device directly but sell or install it to others. It's usually an integral team of many roles. The organization account only can be created by its parent organization and could have many roles in an account.

Owners



Owners mean the person or the company who own the power plant and device for self-using and not for sale. Owner account can be registered by itself or created by the organization account.

Solinteg Technicians



Solinteg technician account is allowed to monitor and manage all the sub-level accounts, plants, and devices from organizations and owners for convenient O&M purposes.

Account Registration-For Owners

Two ways of acquisition of owner account

Method 1

- Access <https://www.solinteg-cloud.com/> for new account registration.
- Click “[Create an account](#)”.
- Input a working properly email address and your name.
- Click the “Send” button behind the verification code.
- Input the verification code received in your registered email.
- Set your own password according to the password requirements.
- Tick the box in front of the “Terms of Use”.
- Click the “[Owner Registration](#)” button.

The screenshot shows the registration process on the website [solinteg-cloud.com](https://www.solinteg-cloud.com/). The process starts with a navigation bar containing a lock icon, the domain name, a chat icon, and a refresh icon. A blue arrow points from the refresh icon to a button that says "New account? [Create an account](#)".

Below the navigation bar, the registration form is divided into three main sections:

- Email and Name Section:** The "Email" field contains "guoxm2006@sohu.com". The "First name" field contains "claire" and the "Surname" field contains "guo".
- Verification Code Section:** The "Verification code" field contains "515351". A blue "Send" button is located to the right of the field.
- Password Section:** The "Password" field contains "....." and the "Confirm Password" field contains ".....". Both fields have an eye icon to toggle visibility. Below the password fields, there is a radio button that is selected, with the text "I have read and accepted the [Terms of Use](#)". A note below reads: "• If you need to register an organization account, please contact your device supplier."

At the bottom right of the form, there is a large blue button labeled "Owner Registration".

Account Configuration-For Owners

Method 1

- The system will take you to the new page “System Settings” after the registration succeeded.
- Set the “Timezone” of your location by click the down arrow or fuzzy search.
- Input the electricity price according to the feed-in-tariff policy or local electricity price.
- Set the electricity price currency unit.
- Select your preferred time format from the list.
- Click the “Next” button.
- Then you will go to the “Plants” page.

System Settings

Timezone

Electricity Price Setting

Currency

Time Format

System Settings

Timezone

Beijing(UTC+08:00)

Electricity Price Setting

0.6

Currency

¥(CNY)

Time Format

DD.MM.YYYY

Next

Account Creation-For Owners

Create owner account and power plant at one time

Method 2

- Sign in the distributor account.
- Move the cursor to “Management” and click “Plant Management”.
- Click “Add Plant”
- Fill in the email of the owner of the power plant.
- Fill in the other blanks marked with asterisks such as plant name, plant type, and total string capacity
- Choose the related organization , and click “Next”.

The screenshot displays the Solinteg Academy user interface. At the top, a dark blue navigation bar contains the word "Management". Below this, a dropdown menu is open, listing several options: "Plant Management", "Device Management", "Organization Management", and "Device Log". The "Plant Management" option is highlighted in a lighter blue. To the right of this menu is a white button with a blue plus sign and the text "Add Plant". Below the navigation elements is a form for creating a new plant. The form consists of three main sections, each with a label and a text input field. The first section is labeled "Owner Email" with a question mark icon and contains the placeholder text "Please enter the email address of the owning user". The second section is labeled "* Plant Name:" and contains the placeholder text "Please input plant name". The third section is labeled "* Plant Type:" and contains the placeholder text "Please select plant type" with a downward arrow icon. Below these three sections is a fourth section labeled "* Related Organization:" which contains a dropdown menu with the selected option "Solinteg Demo Account" and a downward arrow icon. At the bottom right of the form is a blue button with the text "Next".

Account Creation-For Owners

Fill in the “Location” information

- Go to the next page of the “Location” setting.
- Select the plant located country or region by clicking the down arrow.
- Select the time zone of the plant location.
- Click the “Selection” button and a map will pop up, looking for the address on the map and double-click it. Or search the location by entering keywords in the search box.
- Click the “Confirm” button.
- Click the “Next” button.

Add power plant

1 Installation Info — 2 Location — 3 Revenue setting

* Country/Region: 中国大陆 (China mainland)


* Timezone: UTC-12:00 (International Date Line West)

* Location:

Detailed Address:

江苏省无锡市梁溪区崇安寺街道无锡市名人故居文物管理处秦邦宪故居

Search for geographic location



高德地图 © 2023 AutoNavi - GS(2021)6375号

Account Creation-For Owners

Set “Electricity Price” information

- Set the electricity price according to the local subsidy policy or electricity price / Watt.
- Set the currency unit.
- Click the “Complete” button.
- An owner account with a plant inside is created successfully.

Add Device

- After created successfully, you can choose to add device or close the page
- If choose to add device, input the device name,SN,check code
- If you want to add new device, Click “Device management”- “Add Device”


The image shows two overlapping screenshots from a web application. The top screenshot is titled 'Add power plant' and shows a progress bar with three steps: 'Installation Info', 'Location', and 'Revenue setting' (which is the active step, indicated by a blue circle with the number 3). Below the progress bar, there are two input fields: '* Revenue setting:' with the value '1' and '* Currency Unit:' with a dropdown menu showing '¥(CNY)'. At the bottom right of this form are 'Back' and 'Complete' buttons. The bottom screenshot is titled 'Add Devices' and shows a green checkmark icon with the text 'Created successfully'. Below this, there are three input fields: '* SN:', '* Check Code:', and '* Device Name:', each with a placeholder text 'Please enter...'. At the bottom right of this form is an 'Add Now' button. At the bottom left of the 'Add Devices' form, there are two buttons: 'Add Devices' and 'Turn off'.


Device Management

+ Add Device

Account Creation-For Organizations

The organization account only can be created by its parent organization

- Sign in the organization account.
- Move the cursor to “Management” and click “Organization Management”.
- Click the “+” button.
- The sub-organization code is automatically generated by the system, if you don’t like the code, refresh it by click button 
- Fill in all the blanks marked with asterisks such as distributor company name, contact person, email, country, and address.
- Click the “OK” button.
- The registered email will receive a registration succeeded notice with account and password information.
- The new organization account will appear in your account.



The screenshot shows the 'Management' and 'Organization Management' tabs at the top. Below them is a search bar with the text 'Company Name/Email/Organization C...' and a search icon. A '+ ' button is also present. The main form is titled 'Create Subordinate Organization' and contains the following fields:

- * Sub-Organization Code: DB551055 (with a refresh icon)
- * Company Name:
- * Contact Person:
- * Email:
- * Country/Region: Select Country/Region (dropdown menu)
- * Detailed Address:
- Default password: SolarEnergy




At the bottom right, there are 'Cancel' and 'OK' buttons.



Solinteg Cloud Operation Interface Introduction

SOLINTEG

Interface Introduction-Overview Of All Plants



- ① All power plants are categorized and counted by the working status, the number in the circle is the total plant quantity.
- ② All devices in power plants are categorized and counted by the working status, the number in the circle is the total device quantity.
- ③ Power plant system performance by different counting periods.
- ④ PV generation +other generation column.
- ⑤ Plant generation ranking by unit performance.
- ⑥ Environmental performance

Interface Introduction-Plants

Plant Status Plant Type Wuxi Wattsonic Energy Technolo... Plant Name/SN/Email Search Reset

Status	Plant Name	Address	Unit Production(kWh / kWp)	Current Power(kW)	E-today(kWh)	E-total(kWh)	Last update time
	RD Zasterova Habartov	Uhelná 895, 357 09 Habarto...	0.03	0.192	0.2	1,345.9	08:59:18 29.01.2023
	FVE Sobici Vysoka 6kW	Na Vinici 449, 503 31 Vysoká...	0.03	0.328	0.2	4,127.3	08:59:14 29.01.2023

Plant Status

Normal
Faulty
Offline

Categorize plants by system working status.

Plant Type

Residential Plant
Utility Plant
C&I Plant
Energy Storage Plant

Categorize plants by the plant type

Wyy first level account

Wyy first level account
├ test wyy 0915 V1.6
└ ABC SOLAR

Categorize plants by the organization, which can quickly sort out all power plants in an organization.

Plant Name/SN/Email Search


Search a specific plant by the owner's email, plant name or serial number

- All power plants your account manages will be listed on this page, and you can quickly sort them out by different dimensions.

Interface Introduction-Overview Of A Single Plant


Plants / hybrid pv system

Overview Device List



- ① Single plant energy generation is counted by day/month/year and lifetime.
- ② Energy flow animation, clearly show the system energy generation and consumption.
- ③ Plant basic introduction including address, type, weather, connection date and system capacity.

Interface Introduction-Overview Of A Single Plant



Interface Introduction-Device List/Device Details

Plants / Solinteg Academy Test

Overview **Device List** Basic Info

+ Add Device Batch delete

<input type="checkbox"/>	Status	Device Name	SN	Device Type	Remote - Local	Model	Operate
<input type="checkbox"/>	■	Academy test	B11220011063014C 99.9%	Hybrid Inverter	WiFi	SELFA SFH 10.1	✎ ↑↓ 🗑

Plants / Solinteg Academy Test / Academy test

← Real-time Info Historical info

Inverter basic parameters		Battery Parameters		Inverter AC parameters			
10:37:45 31.07.2023		10:37:45 31.07.2023		10:37:45 31.07.2023			
Device Status	Generating	Battery Status	Normal	L1	L2	L3	
Device Name	Academy test	Battery_ID Set	WattLI_HV	AC Voltage(V)	242.3	242.2	244.3
SN	B11220011063014C	Battery Power	1.105 kW	AC Current(A)	0.9	6	1.6
Check Code	357320	Battery Voltage	247.0 V	AC power(kW)	0.11	1.459	0.284
Device Model	SELFA SFH 10.1	Battery Current	4.2 A	Back-Up load voltage(V)	241.3	241.3	241.3
Device Type	Hybrid Inverter	Battery Temperature	28.7 °C	Back-Up load current(A)	0.2	0.2	0.3
Firmware Version	V1.0.0.0-V12.28.1.0	SOH	99.88 %	Back-Up load power(kW)	0.045	0.035	0.03
Rated Power	10.0 kW	SOC	99.86 %	Back-Up Frequency(Hz)	50.03	49.99	49.99
Work Mode	General Mode	Charge current limit	2.4 A	Grid power(kW)	0	-1.267	-0.009
Export Limit	On	Discharge current limit	50.0 A				
Feed in Grid	0.0 %	Min Cell Voltage	3.348 V				
Total operation time	1029 H	Max Cell Voltage	3.501 V				
Inverter Temperature	47.3 °C						
Current Power	511.00 W						
Daily generation	6.80 kWh						
E-total	1.11 MWh						

PV Side				10:37:45 31.07.2023			
	Voltage(V)	Current(A)	Power(kW)				
PV1	425.7	0.7	0.3				
PV2	428.7	0.6	0.26				

Click the “Device List” to check all devices added to the power plant.

Click the “Device Name” to check the detailed info of all system modules.

Interface Introduction-Device Curve

← Real-time Info **Historical info**

Click "Historical info" to view device info in the curve format.

Please select parameters

PV Panel

- PV Power
- PV1 input current
- PV2 input current
- PV1 input voltage
- PV2 input voltage

Battery

- Battery Power
- Battery Current
- Battery Voltage
- SOC
- Min Cell Voltage
- Max Cell Voltage
- Charge current limit
- Discharge current limit

Inverter AC side

- AC power
- On-Grid L1 current
- On-Grid L2 current
- On-Grid L3 current

Clear Confirm

30.01.2023

More parameter curves can be generated by selecting them from the list.



Solinteg Cloud Operation Management

SOLINTEG

Plant Management

Management


Plant Management

Device Management









Organization Management


Device Log

Click “Management”, “Plant Management”, and you will see a list of plants in your account featured with some operation buttons.




The screenshot shows the SOLINTEG Plants Management interface. At the top, there are navigation tabs: Overview, Plants, Management, Alarm, and Firmware upgrade. Below the navigation is a search bar with fields for 'Wyy first level account', 'Type', and 'Plant Name', along with 'Search' and 'Reset' buttons. A table lists four plants with columns for No., Plant Name, Total String Capacity(k...), Address, Creation time, Owner Email, Plant Type, Plant Permission, and Operate. The table includes icons for edit and delete. At the bottom right, it shows 'Total records: 4' and a pagination control for 10 / page.

No.	Plant Name	Total String Capacity(k...	Address	Creation time	Owner Email	Plant Type	Plant Permission	Operate
1	Energy Storage ...	9.67	Nad Vrbim 537, 664 52 Sokolnice, Czechia	15.09.2022	Lovely_Grogu@163.com	Residential Plant	Self-created	 
2	hybrid pv system	12.75	V7Q7+5P Wolfertschwenden, Germany	2022-09-17T00:00	elena.lenu613@gmail.com	Energy Storage ...	Authorized by others	 
3	On-Grid PV Syst...	9.72	2201 Zambales - Pangasinan Rd, Iba, Zambales, Philippines	2022-09-19T00:00	Lovely_Grogu@163.com	Residential Plant	Self-created	 
4	Claire-test	5	江苏省无锡市梁溪区扬名街道中南路394号公交三场	2022-09-21T00:00	635507810@qq.com	Residential Plant	Self-created	 




The screenshot shows the 'Edit Plant' form with the 'Installation Info' tab selected. Fields include: Owner Email (Lovely_Grogu@163.com), Plant Name (Energy Storage Plant), Plant Type (Residential Plant), Grid-tied Date (15.09.2022), Total String Capacity (9.67), Number of Solar Panel (12), Organization Code (DB229000), and a Plant Image upload area. A blue circle with the number '2' is overlaid on the bottom left of the form.



The screenshot shows the 'Edit Plant' form with the 'Location' tab selected. Fields include: Country/Region (Česko (Czech Republic)), Timezone (Berlin(UTC+01:00)), Location (Nad Vrbim 537, 664 52 Sokolnice, Czechia), and a map for detailed address selection. A blue circle with the number '2' is overlaid on the bottom left of the form.

- ① Click to quickly enter the device management page.
- ② Click to edit the plant info such as installation info, location, and subsidy price.
- ③ Click to delete the power plant.



The screenshot shows the 'Edit Plant' form with the 'Electricity Price Setting' tab selected. Fields include: Electricity Price Setting (0.63) and Currency (¥(CNY)). A blue circle with the number '2' is overlaid on the bottom left of the form.

Device Management

Management

Plant Management

Device Management

Organization Management

Device Log

1

Method 1

Click “Management”, “Device Management” to enter the device management page.

Wyy first level account	Plants	Model	Device Name/SN	Search	Reset				
						Add Device Batch delete			
<input type="checkbox"/>	Device Name	Model	Plant Name	SN	Check Code	Comm M...	Master Firm...	Slave Firmw...	Operate
<input type="checkbox"/>	hybrid 12	MHT-12K-25	hybrid pv system	011210010273015C	418003	WIFI	V1.0.0.0	V16.93.1.0	Edit Delete Configure
<input type="checkbox"/>	#01 hybrid inverter	MHT-10K-25	Energy Storage Plant	A112100102130045	389987	WIFI	V1.0.0.0	V16.90.1.0	Edit Delete Configure
<input type="checkbox"/>	#02 on-grid	STS-8KTL	On-Grid PV System (Export Li...	A10210010340301A	102250	WIFI	V3.5.0.0	V27.24.1.0	Edit Delete Configure

Method 2

								Add Plant	
No.	Plant Name	Total String Capacity(k...	Address	Creation time	Owner Email	Plant Type	Plant Permission	Operate	
1	Energy Storage ...	9.67	Nad Vrbim 537, 664 52 Sokolnice, Czechia	15.09.2022	Lovely_Grogu@163.com	Residential Plant	Self-created	Device Management Edit Delete	

Click the “[↗](#)” button behind the plant on the plant management page to enter the device management page.

[Add Device](#) [Batch delete](#)

Operate



Click to edit the device name.



Click to delete the device from the plant (your history data cannot be restored if deleted the device).



Click to configure device parameters such as grid, power control, protection, feature, and battery parameters.



The parameter configuration must be done by a qualified and well-trained engineer with guidance from Solinteg.

Device Parameter Configuration

Parameter Settings Academy test

Grid Parameters

Safety code settings: Czech(A1) *Set according to local safety regulation requests.*

Fault reconnection time: 60 s

Unbalanced Output: *Default to open to enable phase unbalanced output on the on-grid side*

Parameter Settings Academy test

Power Control

Export Limit: *Enable the Export limit if needed*

Feed in Grid: 0.0 *Set the percentage of power allow exported to the grid*

Maximum output power: *Set the max.output power according to your local requirement*

Reactive Mode: *OFF by default. Choose the mode if you want inverter output reactive power*

OFF
The PF is fixed at +1.000.

PF
The reactive power can be regulated by the parameter PF (Power Factor).

Qt
The reactive power can be regulated by the parameter fixed Q(in Pn%).

Cosφ(P)

Disclaimer | Set | Refresh | Cancel

Device Parameter Configuration

Parameter Settings Academy test ☁



Parameter Settings Academy test ☁

Grid Parameters	OV/UV settings
Power Control	Level-1 UV protection threshold: <input type="text" value="195.50"/> V
Protection Parameters	Level-1 UV protection time: <input type="text" value="4.90"/> s
Feature Parameters	Level-1 OV protection threshold: <input type="text" value="264.50"/> V
Battery Parameters	Level-1 OV protection time: <input type="text" value="4.90"/> s
Load Management	OF/UF settings
Meter checking	Level-1 UF protection threshold: <input type="text" value="47.50"/> Hz
Maintenance	Level-1 UF protection time: <input type="text" value="1.00"/> s
	Level-1 OF protection threshold: <input type="text" value="51.50"/> Hz

Disclaimer Set

Grid Parameters	Multiple Inverter Role: <input type="text" value="Independent"/>	If inverter in parallel system, change the role as "master" or "slave"
Power Control	WorkMode Set: General Mode Economic Mode UPS Mode Off-grid Mode	
Protection Parameters	Export Control: <input type="text" value="Hard"/>	
Feature Parameters	On/Off-grid switch: <input checked="" type="checkbox"/>	Keep this function enabled, or inverter can't switch between on/off grid
Battery Parameters	MPPT parallel connection: <input type="checkbox"/>	
Load Management	N-PE check: <input checked="" type="checkbox"/>	
Meter checking		
Maintenance		

Click the workmode to change it

Disclaimer Set Refresh Cancel

👉 The operation of protection parameters must be done on the guidance of Solinteg after-sales engineer.

Device Parameter Configuration

Parameter SettingsAcademy test

Parameter SettingsAcademy test

Grid Parameters

Battery_ID Set:

WattLi_HV

Select compatible battery brands from the list

Power Control

SOC on-grid protection:

Protection Parameters

On-grid End SOC:

20.0

%

Feature Parameters

Off-grid SOC protection:

Battery will stop discharge power when the battery level reaches the set value

Battery Parameters

Off-Grid End SOC:

20.0

%

Load Management

Period Settings:

Set

Meter checking

Maintenance

Grid Parameters

Load Management:ⓘ

--

Disable

ManualMode

SmartMode

Disable by default, choose management mode, then set the control parameters

Power Control

Protection Parameters

Feature Parameters

Battery Parameters

Load Management

Meter checking

Maintenance

Disclaimer

Set

Refresh

Cancel

Disclaimer

Set

Refresh

Cancel

Device Parameter Configuration

Parameter SettingsAcademy test ☁

Parameter SettingsAcademy test ☁

X

Grid Parameters

Power Control

Protection Parameters

Feature Parameters

Battery Parameters

Load Management

Meter checking

Maintenance



--

--

--

This function will check the phase sequence of smart meter and the direction of CT. Make sure the Inverter, Battery and smart meter normal before start this test.

Grid Parameters

Power Control

Protection Parameters

Feature Parameters

Battery Parameters

Load Management

Meter checking

Maintenance



Start



Stop



Restart

The normal working inverter won't react to this operation, and the waiting mode inverter will enter working status after clicking this button.

The normal working inverter will enter waiting mode when clicking this button. You can maintain the battery or PV after powering off the inverter.

When the inverter works abnormally, clicking this button to restart the inverter sometimes can solve the problem.

Device Parameter Configuration-Owner Account

The image displays three screenshots of the 'Parameter SettingsHybrid inverter#01' configuration interface. Each screenshot shows a different section of the configuration page, with a 'Disclaimer' and 'Set', 'Refresh', 'Cancel' buttons at the bottom.

- First Screenshot:** Shows the 'Power Control' section with 'Export Limit' (toggle on) and 'Feature Parameters' with 'Feed in Grid' (input field: 0.0 %).
- Second Screenshot:** Shows the 'WorkMode Set' section with four buttons: 'General Mode' (selected), 'Economic Mode', 'UPS Mode', and 'Off-grid Mode'.
- Third Screenshot:** Shows the 'Battery Parameters' section with 'SOC on-grid protection' (toggle on), 'On-grid End SOC' (input field: 20.0 %), 'Off-grid SOC protection' (toggle on), and 'Off-Grid End SOC' (input field: 70.4 %).

Remote parameter configuration privileges of the owner's account are relatively low, only can set export limit/work mode/battery parameters.
There is no export limit setting when the safety code is VDE4105/Austria/Switzerland

Organization Management

Management

Plant Management

Device Management

Organization Management

Device Log

Click “Management”, “Organization Management” to enter organization management page to create accounts for your sub-level organizations or your internal team members.

Organization Account Creation

The method of creating organization account has been introduced on page 16, please go to page 16 for reference.

Company Info Internal Account

[Add Account](#)

No.	Username	Email	Role	Operate
1	wyy	grogu_gi@163.com	Super Administrator Me	

Add Account

* Username:

* Email:

* Role:

Default password:

Administrator

O&M

Visitor

Permissions of the role:

Administrator has the privilege of operating and managing all accounts, plants, and devices.

O&M can manage all plants, devices, and sub-level organizations.

Visitor can only view all plants and devices.

Cancel

OK

No.	Username	Email	Role	Operate
1	wyy	grogu_gi@163.com	Super Administrator Me	
2	claire.guo	mengmeng_cool@126.com	O&M	

Internal Account Creation

Click “Internal Account”

Click “Add Account”

Input the account info as the system requested and click the “OK” button.

Company Name/Email/Organization C...

Wyy first level account
test wyy 0915 V1.6
ABC SOLAR

Search the organization account by entering company name, email, and organization code.

Check all organization accounts that are managed by you by clicking the unfold button.

Company Info

Internal Account

Company Name: Wyy first level account
Contact Person: wyy
Contact Email: grogu_gi@163.com
Country/Region: 中国大陆 (China mainland)
Address: xinwu part
Organization Code: DB229000
Creation time: 15:12:42 01.09.2022


Account Settings

The screenshot displays the 'Account Settings' interface with three tabs: 'Basic Info', 'General Info', and 'Company Info'. The 'Basic Info' tab is active, showing fields for 'First name', 'Email', and 'Password'. The 'General Info' tab shows 'Timezone', 'Time Format', 'Parameter setting (password verification)', 'Electricity Price Setting', 'Currency', and 'Language'. The 'Company Info' tab shows 'Company Name', 'Contact Person', 'Contact Email', 'Country/Region', 'Address', 'Organization Code', and 'Superior Distributor Code'. A callout box points to the 'Portrait' icon in the top right corner and the 'Personal info' link in the left sidebar, instructing the user to check their account profile.

This screenshot shows the same 'Account Settings' page with callouts explaining how to edit different sections. The left sidebar has 'Personal settings', 'General settings', 'Company settings', and 'Dashboard settings'. Callouts indicate: 'Edit the personal info by clicking the personal settings.' (pointing to 'Personal settings'), 'Edit the general info by clicking general settings' (pointing to 'General settings'), and 'Edit the company info by clicking the company settings' (pointing to 'Company settings'). The main content area shows the 'Basic Info' tab with fields for 'Username', 'First name', 'Email', 'Password', 'Timezone', 'Parameter setting (password verification)', 'Electricity Price Setting', 'Currency', 'Language', 'Company Name', 'Contact Person', 'Contact Email', 'Country/Region', 'Address', 'Organization Code', and 'Superior Distributor Code'. Each field has an 'Edit' button next to it.

Download Center

English ▾ Demo

 **Demo**
grogu_gi@163.com
DB229000

Personal info


System settings

Download Center

Log out







Browser address bar: <https://www.solinteg.com/download/>

SOLINTEG Integ M ▾ Integ O Integ R Integ E Integ ONE ▾  ▾ MENU

Download

Product Related

| Integ M

			
3-8KW Hybrid Inverter	4-12KW Hybrid Inverter	10-20KW Hybrid Inverter	25-50KW Hybrid Inverter

Move your cursor to the account icon, click the Download Center, system will go to the download part of Solinteg website.




Solinteg Cloud Operation 24 Alarms

SOLINTEG

Alarm Setting



 **wyy**
grogu_gi@163.com
DB229000

Personal info

System setting

Log out

Click the "Portrait" on the right top corner and "Personal info" to check your account profile.

Personal settings

General settings

Alarm settings

Company settings

*** Whether to push alarms**

Off

Alarm level Fault Protection

Push method Email Push APP Push

Email Push Language

English

*** Whether to push alarms**

Off

On

Off

Choose whether to receive the alarm information or not.

Alarm level Fault Protection

The alarms are sorted into two levels, fault and protection. You can choose to receive one or both.

Push method Email Push APP Push

Choose which way to receive the alarm information, in email or APP, or both.

Email Push Language

English

English

Español

Polski

Portugués

中文



Deutsch

Italiano




Čeština

Choose the language of your push information

Alarm Search

 Overview Plants Management Alarm Firmware upgrade English 

Alarm type Alarm Status Alarm name Start date → End date Plant Name/SN Search

Plant Name	Device Name	SN	Alarm type	Start time	Alarm name	Alarm Status	Operate
Hybrid PV System	test device	8112200171030795	Protection	16:15:36 29/01/2023	BMS Comm Fault	Not repaired	
直连	office	A112200109930797	Protection	16:11:57 29/01/2023	BMS Comm Fault	Not repaired	
Hybrid PV System	test device	8112200171030795	Protection	08:48:32 29/01/2023	Mains Lost	Restored	

Jan 2023

Su	Mo	Tu	We	Th	Fr	Sa	Su
	1	2	3	4	5	6	7
	8	9	10	11	12	13	14
	15	16	17	18	19	20	21

Categorize plants/devices by alarm type

Categorize plants/devices by alarm status

Categorize plants/devices by directly input the alarm name

Categorize plants by alarm start date and end date

Search a specific plant by plant name or serial number

- All alarm information of your plants the account manages will be listed on this page, and you can quickly sort them out by different dimensions.

Alarm Operate

Plant Name	Device Name	SN	Alarm type	Start time	Alarm name	Alarm Status	Operate
Elsner_Mnichovo Hradiste	Elsner_Mnichovo Hradiste	5112200151930148	Protection	14:33:33 29.01.2023	Mains Lost	Not repaired	

Operate



[← Back](#)

Click the “Operate”, check the alarm information details

Plant Name:	Hybrid PV System	Alarm device basic information
Device Name:	test device	
SN:	8112200171030795	
Start time :	08:48:32 29/01/2023	Alarm start time
Alarm type:	Protection	Alarm level, protection or fault
Alarm name:	Mains Lost	Alarm name description
Alarm Status:	Restored	Restored or not repaired
Recovery time:	13:25:31 29/01/2023	Alarm recovery time
Causal analysis:	Grid power outage, AC switch or circuit is disconnected.	Why alarms appear
Processing measures:	1. Check whether the mains supply is lost. 2. Check whether the AC cable wiring is correct.	How to check and settle the alarms



Solinteg Cloud Operation Firmware Upgrade


SOLINTEG

Firmware Upgrade-Add



Start date → End date Operator

Operator	Device Type	SN	Device Model	Upgrade method	Upgrade Version	Creation time	Upgrade det
grogu_gi@163.com	Hybrid Inverter	A11220010093009A	MHT-20K-40	Upgrade Now	V1.0.0.0-V12.28.2.0	16:32:36 12.06.2023	Succeed



Click the "Add", add devices to upgrade list

Firmware upgrade ✕

Select device:

Current version: V1.0.0.0-V16.38.2.0

Latest version: V1.0.0.0-V16.42.2.0

Firmware Description:

Firmware I

1. Modify protection value.
2. Add Hard/Soft control function.
3. Optimize the operating status.
4. Optimize the fan detection logic.
5. Fix the known issue.

Upgrade process may interrupt device running, please confirm the user authorization has been obtained

Input the device SN or plant name to search for the device you want to upgrade

System shows the current and latest version

Check the firmware description, confirm if you continue to upgrade

Firmware Upgrade-Export

Start date → End date Operator

Operator	Device Type	Firmware Type	Upgrade method	Upgrade Version	Creation time	Upgrade details	Operate
meng.ni@solinteg.com	Inverter	ARM	Upgrade Now	V1.0.0.0-V6.23.1.0	11:21:11 07.12.2022	Succeed	<input type="button" value="Detail"/>
meng.ni@solinteg.com	Inverter	DSP	Upgrade Now	V1.0.0.0-V2.23.1.0	11:05:46 07.12.2022	Succeed	<input type="button" value="Detail"/>

Click the "Export", download the upgrade history list

A	B	C	D	E	F	G
Operator	Device Type	Firmware Type	Upgrade Method	Upgrade Version	Creation Time	SN
meng.ni@solinteg.com	Inverter	DSP	Upgrade Now	V1.0.0.0-V2.23.1.0	11:05:45 07.12.2022	A112200171030153
meng.ni@solinteg.com	Inverter	DSP	Upgrade Now	V1.0.0.0-V2.23.1.0	11:05:46 07.12.2022	A112200171030153
meng.ni@solinteg.com	Inverter	DSP	Upgrade Now	V1.0.0.0-V2.23.1.0	11:05:46 07.12.2022	A112200171030153
meng.ni@solinteg.com	Inverter	ARM	Upgrade Now	V1.0.0.0-V6.23.1.0	11:21:11 07.12.2022	A112200171030153

H	I	J	K	L	M	N
Device Name	Plant Related	Start time	End time	Pre-upgrade version	Upgraded version	Upgrade result
	固件测试	11:05:45 07.12.2022	11:07:46 07.12.2022	V1.0.0.0-V2.21.1.0	V1.0.0.0-V2.23.1.0	Upgrade failed
	固件测试	11:05:46 07.12.2022	11:07:34 07.12.2022	V1.0.0.0-V2.21.1.0	V1.0.0.0-V2.23.1.0	Upgrade failed
	固件测试	11:05:46 07.12.2022	11:09:22 07.12.2022	V1.0.0.0-V2.21.1.0	V1.0.0.0-V2.23.1.0	Upgraded successfully
	固件测试	11:21:11 07.12.2022	11:58:56 07.12.2022	V1.0.0.0-V2.23.1.0	V1.0.0.0-V6.23.1.0	Upgraded successfully



Solinteg APP Operation


SOLINTEG

Solinteg App


Introduction

Solinteg App is the portable version of Solinteg cloud monitoring allowing both organization users and owners to monitor and manage their plants and devices at any time anywhere.

Solinteg App operation steps are similar to the Solinteg-cloud, and here we won't present the detailed steps about account registration, plant creation, and plant management.



Overview Page




Device information Page




SolintegSet Operation

SOLINTEG


Connection & Log In




Power on the inverter and search for the WiFi released by the inverter




Open the App and click "Scan", you will see inverter WiFi appeared on the list



Select a role to enter the configuration page




Input password (contact Solinteg service team for the password), Click "Log In"




Enter the homepage of the inverter, you can see the basic parameters of all modules in the system


Settings & Hybrid Configuration




Click "Settings", two menus of grid protection parameters and hybrid inverter configuration will appear.




Click "Grid Protection Parameters" to modify the inverter parameters. Modify under the instruction of professionals.



Select the battery brand that you are using from the list, and click "Next"



Select safety code according to the inverter installation place, and click "Next"



Select a work mode that you preferred, and set the detailed parameters according to requirements.

Definition Of Four Work Modes

General Mode

PV power is sufficient, power from the PV will firstly supply loads, then excess power charge battery, and any surplus power will be fed to the grid.

PV power is insufficient to satisfy loads, the battery will discharge power to fill the power gap, and the grid will join in if it's still not enough.

UPS Mode

Power grid is connected, power from PV or grid will firstly charge the battery until it's full, and loads will be supplied by the grid during charging period. Battery will not discharge power when the grid is connected.

Power grid fails, and PV power is insufficient to meet the loads' consumption, the battery will discharge power to supply loads connected to the back-up port.

Economic Mode

This mode is typically used in areas where with peak and valley electricity prices to assist clients in optimizing their energy costs. By configuring the App, customers can charge power from the grid during valley hours.


Customers can also discharge power during peak hours by configuring the App, and the battery will discharge electricity to supply loads or feed to the grid in this instance.

Off-grid Mode

In the purely off-grid mode, power from PV will supply the back-up loads first and then charge the battery if there's surplus power. When the power from PV isn't enough, the battery will discharge to supply back-up loads together with PV.




Note: If there's no grid connection when configuring the hybrid system, please set the work mode to "Off-grid" to enable the power output in back-up port and switch to other modes when grid comes back.

General Mode Configuration



- Export limit function ON/OFF switch
- Set the percentage of power allow exported to the grid
- Peak load shifting function ON/OFF switch
- Set the max power that signed with the grid
- On-grid SOC ON/OFF switch
- On-grid SOC percentage setting. When the battery level drops to this value, battery will stop discharge.
- Off-grid SOC ON/OFF switch
- Off-grid SOC percentage setting. When the battery level drops to this value, battery will stop discharge.
- Three-phase unbalanced output ON/OFF switch. Turn on the switch to enable on-grid unbalanced output.

Economic Mode Configuration



Select charge or discharge to set the detail param.

Select battery charge sources(PV only or PV+Grid)

Set the max charge power percentage (calculated on the inverter rated output power)


Set the force charge starting time

Set the force charge ending time

Note: The end time must be bigger than the start time. Eg. The start time from 17:30, the end time must be less than 23:59, if you want to continue charging the battery, you can set a new charge period from 0:00 to a new end time.

You can set up to 6 charging & discharging periods in total

UPS & Off-Grid Modes Configuration




Off-grid SOC ON/OFF switch

Off-grid SOC percentage setting, suggest to set to 1-DOD value


Did you know?

Off-grid settings are the same as UPS mode settings, and the difference is their working logic. For the UPS mode, it usually used in the situation grid connected but power outages always occur. The battery is used as backup power only discharging when grid fails. Off-grid mode usually suits for a long time with no power grid.


About




Click "About" to view the account information



Click the arrow behind "Personal Details" to enter the password modification page



Click the arrow behind "Change password" to change the password



Click the arrow behind "After-sale service" to find out our global service contact

THANK YOU

www.solinteg.com